

pop
SONIC



SONIC SPONGE
Antibacterial Cleaning Device

Hello! Thanks for purchasing this Authentic Pop Sonic product. For questions about your product please call Pop Sonic customer service at (800) 772-9174 or email help@shoppopsonic.com.

WHAT'S IN THE BOX

1 SONIC SPONGE




2 USB Cord



3 Manual



Product features



GETTING STARTED WITH YOUR SPONGE

- Fully charge your Sponge by connecting the cord into the sponge charging port, then connect the other side of the cord into a charging cube then plug the cube into a wall outlet.
- When charging the LED light will blink, when fully charged the LED light will stay solid.
- After fully charging your sponge, disconnect the charging cord and store in a safe, dry place.
- When fully charged, your sponge battery should last around 100 minutes of constant use.
- Your sponge is waterproof (IPX6) so feel free to use it in the shower. IPX6 protects from heavy splashing and exposure to water but is not meant to withstand prolonged submersion under water.

USING YOUR SPONGE

- The Sonic Sponge is great for everyday facial cleansing, body cleansing, exfoliation, and much more. For facial cleansing it is recommended you use the thinner bristle side while the thicker bristle side is best for deeper cleansing and exfoliation of your body.
- Thorough testing has even proven the Sponge to be durable enough to be effective in household cleaning on counters, dishes, floors, grill grates and more. For these types of activities it is recommended to use the thicker bristle side.
- For all the above activities, it is recommended that you use your everyday skincare lotions, cleansers, and serums. If you are using the Sponge for household chores, it is ok to use common counter sprays, dish soaps, etc. Just make sure there isn't any abrasive material in the ingredients because this could cause damage to the silicone.
- The silicone we use is treated with silver ion powder which makes it antimicrobial. However, it is still recommended that you wash your Sponge with soap and warm water after you have used it. Then store in a safe and dry place.

WARNINGS!

- Keep away from water while plugged in. First, unplug from the USB charging cable then use the product.
- Always unplug the sponge before cleaning.
- It is not recommended that children under 13 use this sponge unless properly supervised by an adult.

Lithium Battery Replacement, Disposal, and Recycling

- Do not attempt to remove lithium ion battery. These types of batteries carry inherent dangers if mishandled and can explode, catch fire, or cause burns if disassembled or are damaged in any way.
- Lithium batteries are subject to local disposal regulations and should not be discarded in regular trash. Check your local law regulations for disposal information.
- Lithium batteries can be recycled. For recycling information, contact your government recycling agency, wasted disposal service, or visit online recycling resources such as www.batteryrecycling.com or www.rbrbc.com.

Warranty

- POP SONIC warrants the Sonic Sponge for a period of 1 year after the original date of purchase, against defects due to faulty workmanship or materials. For warranty claims, you must register your device and log in to your account at www.shoppopsonic.com then select option to make a warranty claim. Our customer service department will then contact you to initiate the warranty procedure.
- This warranty covers working parts. It does not cover damage due to normal usage or accidents such as dropping the device.
- Other exclusions include misuse or neglect to the device. This warranty is void if any other charging cables besides the one you received is used with your device. For any warranty claims, proof of purchase must be provided. For this reason, please keep your receipt for the duration of the warranty period.
- Shipping costs are non-refundable.

Cleaning and Maintenance

- For best results, it is recommended that you clean the sonic sponge after each use.
Clean the surface of the product with gentle soap and rinse it with clean luke warm water to get the best results.
- Avoid using alcohol, harsh chemicals, or any detergents that may defect the product.
- After the product is cleaned, you can air dry it on a flat surface in a room temperature environment.

Specifications

Power system:	Cordless rechargeable lithium ion battery
Battery type:	Lithium Ion 120mAh
Charging time:	1.5 hours
Using time:	100 minutes

Designed and developed by Pop Sonic, LLC
Minneapolis, MN 55344
Made in China
www.shoppopsonic.com